





Tyre labelling information: SANDERO STEPWAY


16"

 **ENERG** 

Continental 0358181



205/60 R 16 92 H C1

	
A	A
B	B
C	C
D	D
E	E

 **71 dB**
ABC



2020/740


16"

 **ENERG** 

Hankook 1025238



205/60R16 92 H C1

	
A	A
B	B
C	C
D	D
E	E

 **71 dB**
ABC



2020/740


16"

 **ENERG** 

Giti Tire A3777

185/65R15 88T C1

	
A	A
B	B
C	C
D	D
E	E

 **69dB**
ABC

2020/740